


Chốt trụ lò xo sóng

スプリングピン 波型

寸法図



寸法表

	d1 MAX	d1 MIN
M1	1.2	1.1
M1.2	1.4	1.3
M1.4	1.6	1.5
M1.5	1.7	1.6
M1.6	1.8	1.7
M2	2.25	2.15
M2.5	2.75	2.65
M3	3.25	3.15
M3.5	3.9	3.7
M4	4.4	4.2
M4.5	4.9	4.7
M5	5.4	5.2
M6	6.4	6.2
M7	7.6	7.3
M8	8.6	8.3
M10	10.6	10.3
M13	13.7	13.4